

## COMMISSIONING OF THE HEAT PRESS

- do not use a lifting device to remove the press from the box
- read the operating manual before commissioning
- use own power supply
- do not use extension cables and multiple plugs
- use the supplied power cable

## MAINTENANCE OF THE PRESS

### Tips for low-maintenance operation

- observe maximum pressure setting
- cover sheet recommended to protect heat platen
- replace worn silicone mat

## DAILY MAINTENANCE WORK TO BE CARRIED OUT

- checking the functions and settings
- do not continue to use the press if it is damaged or malfunctions, contact your dealer

## WEEKLY MAINTENANCE WORK TO BE CARRIED OUT

- cleaning the surfaces of the press and the working area

## MONTHLY MAINTENANCE WORK TO BE CARRIED OUT

- if the heat platen is dirty, clean it with the heat platen cleaner and heat eraser
- relubricate the pressure spindle with temperature-resistant lithium grease

## ANNUAL MAINTENANCE WORK TO BE CARRIED OUT

- relubricate exposed linkage
- check heat platen for cold spots, check calibration

**The heat platen is not rigidly attached, so that mobility when closing the press ensures an optimal pressing process.**

### NOTE

#### Contact:

STAHL'S Europe GmbH • Dieselstraße 62 • 66763 Dillingen • Germany  
Telefon: +49 (0) 68 31/97 33-0 • Fax: +49 (0) 68 31/97 33 45  
www.stahls.de • info@stahls.de